

C-22 M O D É L 333

INSTALLATION INSTRUCTIONS

925 Bow Pulpit  
926 Stern Rail  
949 Stanchions,  
Lifeline

On page two you find the dimensions for installing the Bow Pulpit, Stern Rail, and stanchions with lifelines. Each measurement is from the bow to the centerline of each deck bracket, or from the stern to the centerline of each bracket. The location of the stern lifeline anchor bracket, is the only bracket measured from the stern to the rear on the bracket.

These dimensions are very important for reinforcement pads are fiber-glassed in these areas only, to support mounting brackets for these three (3) accessories.

When mounting these brackets, always use RTV sealer, or a permanent water tight sealer. Seal all bolt hole areas completely to insure water tight fittings.

